

Race Clock – Instructions for Use

The clock measures 130cm x 42cm x 14cm

The clock has a control panel on the end with four buttons. It also has two power clips on leads for attaching to a car battery or battery pack (supplied).



1. Attach power clips to power source (red on +, black on -) ensuring good connection.
2. Press green START button to start the clock.
3. To stop the clock, press both black buttons together.
4. Press the red RESET button to set the clock back to zero. (Only works when stopped.)
5. If required, use the black SET MINS and SET HRS buttons to pre-set clock to a time. Pressing START will continue on from time shown.

The battery pack supplied must be put on charge overnight before use to ensure it is fully charged. (Check the battery level indicator light is green). It should have sufficient power to keep the clock going to the maximum time (i.e. 9:59:59). If needed for longer than this, it is advised to keep the mains lead attached to the battery unit to keep it charging whilst in use.

Switch the battery pack 'on' before use and 'off' again afterwards for safety.



Note : The power clips on the clock are designed to be attached to the nodes of a car battery, so attaching them to the clips on the battery pack can be fiddly to get a good connection. It is **not** a good idea to move the whole unit once the clock is being used in case the clips come undone.